

Fitting & Care Instructions - Basin Waste, Chain & Stay 1 1/4"

- 1) Assemble components as shown on the drawing.
- 2) Apply Sponge gasket to the underside of the waste flange
- 3) On the underside of the basin, where the threaded tail exits, it will be necessary to seal using plumber's putty or silicone sealant.
- 4) Once fitting has been completed, carefully clean all plated surfaces. The finished surfaces on this product are hard and durable and should be cleaned on a regular basis to maintain their appearance. They should only be cleaned with warm soapy water and then wiped with a dry cloth. Under no circumstances should any aggressive or abrasive cleaning agent be used, as this can lead to a deterioration of the high quality finish.

