

Fitting & Care Instructions - Spring Plug Basin Waste 1 1/4"

Assemble components as shown on the drawing.

1. Apply Sponge gasket to the underside of the waste flange.
2. On the underside of the basin, where the threaded tail exits, it will be necessary to seal this using plumber's putty or silicone sealant.
3. Once fitting has been completed, carefully clean all plated surfaces. The finished surfaces on this product are hard and durable and should be cleaned with warm soapy water and then wiped with a dry cloth. Under no circumstances should any aggressive or abrasive cleaning agent be used, as this can lead to a deterioration of the high quality finish.
4. To operate simply push down on the integral plug to close, A further push will raise the plug, allowing the basin to drain.

Note: Illustration refers to the "flat mushroom" slotted tail version, though this instruction is applicable to all "spring plug" variations available (both slotted and unslotted).

